



* Measure to be determined based on chosen context of use and panel material.



1. place supports for panels on the special compartment of base



2. Screw supports onto panel-holder base



3. Fit perforated print into base



4. Place screws into base and into panels, screw to complete fastening